

### Lever on Rose Fitting Instructions

#### Serozzetta, Designer Range, Eurospec and Steelworx

1. In conjunction with lock/latch backset, use the adjacent template.
2. Mark out centre hole **A**, then fixing holes **B1** and **B2** at 38.0mm centres.
3. Using a 5.0mm diameter bit, drill holes **B1** and **B2** at 38.0mm centres as shown.
4. Using a 20.0mm diameter bit, drill hole **A** at the centre location.
5. Put the spindle into one of the levers and securely fix the grub screw, ensuring enough spindle is free to pass through door and to be secured in the opposing lever.
6. Place the lever to the door so the spindle passes through the latch/lock follower and line up the holes on the rose with those pre-drilled in the door.
7. Place the second lever on the opposite side of door and using both the bolts provided, evenly tighten up both bolts, so both lever are secured firmly against the surface of the door.
8. Tighten up grub screw on opposite lever and recheck all fixings are secure. If levers do not operate freely, check alignment of all components.
9. Place and screw on both outer rose covers.

#### Drilling Template

