

1. Mark out centre hole **A** depending on the backset of your lock/latch. Using a 35mm diameter bit, drill centre hole **A** to a depth of 10mm on both sides of the door. Then using a 20mm diameter bit, drill centre hole **A** through the door.

2. Insert the spindle into the lever and securely fix the grub screw, ensure enough spindle is free to pass through the door and to be secured in the opposing lever.








3. Offer the lever up to the door so the spindle passes through centre hole **A** for the latch/lock and mark the fixing holes **B** using the screw holes on the back plate as a guide.

4. Offer the second lever up to the opposite side of the door and use the marking method outlined in step 3.

5. Remove the levers from the door. Using a 2mm diameter bit, drill pilot holes to a depth of 5mm.

6. Offer the levers back to the door and insert the screws. Using a screwdriver fix the levers to the door using the predrilled pilot holes.

7. Once secured to the door, tighten the remaining grub screw and recheck all fixings are secure. If the levers do not operate freely, check alignment of all components.



Maintenance

Ensure all fixings, including grub screws are secure, tighten where necessary. Clean with a soft lint free cloth.